

# DA20-C1 BOLDFACE

<b>ENGINE FIRE ON THE GROUND</b>  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
<b>ELECTRICAL FIRE ON THE GROUND</b>  <b>GEN/BAT MASTER SWITCH — OFF</b>
<b>ABORT</b>  <b>THROTTLE — IDLE</b> <b>BRAKES — AS REQUIRED</b> <b>FLAPS — CRUISE</b>
<b>ENGINE MALFUNCTION IN FLIGHT (SUFFICIENT RUNWAY REMAINING TO LAND)</b>  <b>AIRSPEED — 60 KIAS</b> <b>FLAPS — LDG</b>
<b>ENGINE MALFUNCTION IN FLIGHT (FUEL PRESSURE LOSS)</b>  <b>FUEL PUMP — ON</b>
<b>ENGINE FIRE DURING FLIGHT</b>  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
<b>ELECTRICAL FIRE DURING FLIGHT</b>  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b>
<b>CABIN FIRE IN FLIGHT</b>  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b> <b>CABIN HEAT — OFF</b>

# DA20-C1 BOLDFACE

<b>ENGINE FIRE ON THE GROUND</b>  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
<b>ELECTRICAL FIRE ON THE GROUND</b>  <b>GEN/BAT MASTER SWITCH — OFF</b>
<b>ABORT</b>  <b>THROTTLE — IDLE</b> <b>BRAKES — AS REQUIRED</b> <b>FLAPS — CRUISE</b>
<b>ENGINE MALFUNCTION IN FLIGHT (SUFFICIENT RUNWAY REMAINING TO LAND)</b>  <b>AIRSPEED — 60 KIAS</b> <b>FLAPS — LDG</b>
<b>ENGINE MALFUNCTION IN FLIGHT (FUEL PRESSURE LOSS)</b>  <b>FUEL PUMP — ON</b>
<b>ENGINE FIRE DURING FLIGHT</b>  <b>FUEL SHUTOFF VALVE — OFF</b> <b>CABIN HEAT — OFF</b>
<b>ELECTRICAL FIRE DURING FLIGHT</b>  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b>
<b>CABIN FIRE IN FLIGHT</b>  <b>GEN/BAT MASTER SWITCH — OFF</b> <b>AIR VENTS AND WINDOWS — OPEN</b> <b>CABIN HEAT — OFF</b>